



TECHNICAL SERVICE BULLETIN

Technical Service Bulletin Number-TSB0008 – Loctite Nuts

Date – 05/24/2019

Item, Unit or Assembly Affected – Shift-N-Step

Serial Number(s) Affected – All units prior to SNS570200

Reason for Bulletin – Nuts may come loose and bridge electrical contacts, resulting in unwanted motion.

Action Required – Remove nut, apply Blue Loctite to threads, replace the nut.

Safety Issue? - If occurring on the keyswitch, sensors will be ignored and motion can potentially cause injury.