

# Leadership Series Transfer Seat Base

**B&D**  
Independence, Inc.

• New Central Wiring Distribution Channel -  
(Center bolt has been replaced with a steel bushing)

• New 12" diameter  
swivel gear provides  
smoother turning

• New two position adjustable switch box  
allows you to position it as close  
to the seat as possible

• New repositioned wiring harness eliminates  
the opportunity for accidental damage

• New direct vehicle chassis ground system

• Optional  
Frame Covers  
for O.E.M  
Styling

• New swivel adjustment  
screw allows the seat to be  
adjusted up to 5° towards  
center of vehicle

• New Delrin bearings provide  
improved stability and quieter operation

• Reinforced scissor legs, steel channels, and 1500 lb actuator for greater stability and 500 lb capacity

• New protective cover prevents objects from falling into the actuator

**ComfortSafe**  
FOOT REST

• Signature B&D Direct Mounting System:  
No Drilling Required

*Safe Independent Mobility*