

# BRUNO

*Battery-Powered  
Stairlifts*

# *Electra-Ride™ LT*

*Straight Rail Stairlifts*

BREAKING THE BARRIERS



*New Added Features! Just As Affordable!*



# Adjustable

*The Electra-Ride LT Straight Rail Stairlift makes going up & down the stairs a pleasure!*



## Safety

With adjustable seat height and low footrest height, you will be totally at ease on your Electra-Ride LT. Carrying up to 275 lb (125 kg), the unit moves without hesitation when stopping and starting. The standard swivel seat makes it easy to exit when you reach the top or bottom of the stairs. The Electra-Ride LT meets all ANSI A-18.1 residential requirements.

## Affordable

Electra-Ride LT offers a long list of standard features at a price that will please even the most budget-minded consumer.

## Quiet & Smooth Operation

The rack and pinion drive provides a smooth ride which is exceptionally quiet, while the covered gear rack gives you a clean and attractive rail.

## Compact

The seat, arms and footrest all flip up for a tight park position, making your stairway completely accessible for family and guests.



The arms, seat and footrest flip up, creating plenty of space for others to walk up the stairs.

The Electra-Ride LT's soft start/stop feature provides the smoothest ride without hesitation.

**BRUNO**  
**Electra-Ride™ LT**

Compact • Safe

# Affordable

*You don't have to be limited by stairs anymore, so enjoy the home you love, upstairs and down!*

## Battery-Powered

Using two 12-volt batteries that are powered by an unobtrusive battery charger plugged into a standard household outlet, the Electra-Ride LT features strip charge contacts for more flexibility when parking. You have access to your upstairs and downstairs, even if electrical service in your home is interrupted.



The arms flip up and out of the way for easy wheelchair transfer.

The footplate and carriage safety sensors safely stop you, even if the slightest obstacle is in the way while you ride!



Folding rail option allows full clearance to doorways or hallways without rail obstruction.

The two wireless call/send controls make installation simple and clean with no wires running along the wall.



The Electra-Ride LT's seat swivels at top and bottom of stairs for easy entry and exit.

## SRE-2750 Electra-Ride LT Specifications

### Exceptional Value

- ♦ Locking swivel seat at the top and bottom of the stairway. Seat swivels 67° in each direction (adjustable to 90°) at top and bottom of stairs for convenient exit/entry angles.
- ♦ Two remote, wireless call/send controls.
- ♦ Generous seat size – 17 3/4" (451 mm) between the arms.
- ♦ Footplate and carriage safety sensors.
- ♦ On-board diagnostics make service easier and more precise.
- ♦ Meets all ANSI - A18.1 residential requirements.
- ♦ CSA/C-US listed.
- ♦ Seat belt with buckle.
- ♦ Bruno's Gold Warranty – Five years for major components and two years on parts.

### Convenient Installation

- ♦ Rail installs to within 9 1/2" (241 mm) of the wall.
- ♦ Can be installed on either side of the stairway.
- ♦ Standard track lengths of:
  - 16' (4.9 m) – two 8' (2.4 m) sections
  - 20' (6 m) – two 10' (3 m) sections
- ♦ Optional manual folding rail at bottom.

### Smooth, Powerful Drive System

- ♦ Self-locking worm gear; rack and pinion drive.
- ♦ Maximum rider weight of 275 lb (125 kg)
- ♦ Soft start, solid-state controller delivers a smooth, comfortable ride.

### Battery-Powered Technology

- ♦ Ensures access even during power outages.
- ♦ Powered by two 12V batteries, continuously charged by the power supply plugged into a standard household outlet at either the top or bottom of the stairway.

### Comfort

- ♦ Contoured seat for maximum comfort.
- ♦ Flip-up arms for easy wheelchair transfer.
- ♦ Adjustable seat height for easier entry/exit at top and bottom of stairway.

**BRUNO**  
**Electra-Ride™ LT**

# BRUNO INDEPENDENT LIVING AIDS, INC.®

*manufactures independence products that help people live their lives to the fullest!*

Ask us about our other...

**INDOOR AND OUTDOOR STRAIGHT RAIL and CURVED RAIL Stairlifts and Vertical Platform Lift**



**ELECTRA-RIDE™ ELITE**



**ELECTRA-RIDE™ III**



**OUTDOOR ELITE ELECTRA-RIDE™**



**VERTICAL PLATFORM LIFT**

## OVER 20 DIFFERENT *Vehicle Lifts* INCLUDING:



**OUT-SIDER® MERIDIAN™ SERIES**



**JOEY™ INTERIOR  
PLATFORM LIFT VSL-4000**



**CURB-SIDER® SERIES**



Founded over 25 years ago, Bruno Independent Living Aids, Inc., is a world-wide manufacturer of accessibility products designed to enhance the lives of those challenged by limited mobility. In pursuing this goal, Bruno is proud to be the only U.S. manufacturer of indoor/outdoor stairlifts, interior/exterior scooter, powerchair and wheelchair vehicle lifts and Turning Automotive Seating™ (TAS™) products to be ISO 9001 Certified. This is one of the most stringent, widely-recognized quality standards in the world and your assurance that Bruno is committed to providing you with the highest-quality, most reliable products in the industry. Ask your certified Bruno dealer for details on all Bruno independence products.



Represented by:

**BRUNO INDEPENDENT LIVING AIDS, INC.®**  
1780 Executive Drive, P.O. Box 84, Oconomowoc, WI 53066  
www.bruno.com

## *Revolutionary Turning Automotive Seating™ (TAS™)*



**TURNY™  
ORBIT™ SEAT**



**STOW-AWAY™**

All illustrations and specifications in this brochure are based on the latest product information available at the time of publication. Bruno Independent Living Aids, Inc. reserves the right to make changes at any time without notice. Electra-Ride LT 3/11-11 © Bruno Independent Living Aids, Inc. 2011.



Part #: MKT-SRE-2750