



**Validation Test Data Sheet
Static Load Test,
Ford Transit 2015 Side Entry
AbiliTrax Certification**

Validation Test Data Sheet for Project:

Ford Transit 2015 Side Entry
AbiliTrax Flooring & Lift Installation Kit

Validation Test Name:

Static Load Test

1.0 Procedure

Testing was performed using a Ricon Titanium lift. Lift was installed onto AbiliTrax flooring (AATHF100) using AbiliTrax installation kit (ASLM02). Installation was tested using a 1,000 lbs. working load and a 3x factor of safety. 3,000 lbs. load was applied for a time of 2 minutes.

2.0 Test Data

57870: 2015 Ford Transit Rear Entry Install Kit		
Load on Platform	Time	Result
3000 lbs.	2 minutes	<ul style="list-style-type: none">• No separation, fracture or breakage observed.• No permanent vehicle deformation observed

3.0 Conclusion

Used in conjunction with AbiliTrax floor AATHF100, AbiliTrax lift installation kit ASLM02 is considered to have passed static load testing based on requirements specified in FMVSS 571.403, S7.11.