Work Order No.: 2107B4 Page 1 of 30



FSTL TEST REPORT

FSTL_TENSION

FSC 2PL 3PT GO-ES Spacesaver FOLDAWAY in pos. D in a Ford Transit



Work Order No.: 2107B4 Page 2 of 30

07/00/0004

TEST REPORT

TECT/C) DEDECODMED ON DATE.

| 1E31(3) PERFORIVIED ON DATE. | 0772272021 |
|------------------------------|--|
| TEST LABORATORY: | Freedman Seating Test Lab 4545 West Augusta Blvd. Chicago , IL 60651 |
| TEST REQUESTED BY: | Scott Fenton Fenton Mobility 1209 East 2nd St. Jamestown, NY |
| TEST REPORT REVIEWED BY: | |
| TEST REPORT APPROVED BY: | |
| Note[s]: | |
| N/A | |

This Test Report is provided solely for the use of the party requesting the same identified, and for no other person, entity or purpose. Reproduction of this document is strictly prohibited without the prior written permission of FSTL in each instance.

Full compliance with FMVSS and its Regulations, as set forth under 49 USC 301, et. seq., can only be achieved through proper in-vehicle testing. Freedman Seating Company, its agents, employees, affiliates and subsidiaries ("Freedman Seating") is not liable for damages resulting from the installation of any seat in a vehicle that has not been FMVSS tested or any installation of a seat that deviates from a FMVSS tested installation method. Freedman Seating has no responsibility for the design of any vehicle in which the subject seat may be placed, or any resulting damages. The results documented in this report relate only to the items tested, as described herein.

Work Order No.: 2107B4 Page 3 of 30

SUMMARY OF PROCEDURE

Summary of FSTL_TENSION

A force of 3,000 lb shall be applied to each lap and shoulder belt at $10^{\circ} \pm 5^{\circ}$ above the horizontal plane. In addition, a force equal to 20 times the system mass was applied simultaneously through the CG of the seating system. The required forces must be reached within 30 seconds from the onset of the test then, when reached must be held for 10 seconds.

Work Order No.: 2107B4 Page 4 of 30

TEST FIXTURES

| Fixture # | Description | |
|-----------|-------------------|--|
| PL-002 | Pull Test Machine | |
| | | |
| | | |
| | | |
| | | |

MEASURING EQUIPMENT

| Equipment # | Description | Calibration # |
|-------------|-------------|---------------|
| LC-01 | Load Cell | C2102 |
| LC-02 | Load Cell | C2102 |
| LC-04 | Load Cell | C2102 |
| LC-06 | Load Cell | C2102 |
| LC-015 | Load Cell | C2102 |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |

Work Order No.: 2107B4 Page 5 of 30

Data Sheet

FSTL 4545 w. Augusta Blvd.

4545 w. Augusta Blvd. Chicago, IL.

Work Order No.: 2107B4

| Requirements for compliant test. | Yes/ No / N/A | |
|---|---------------|--|
| Test artifact reached loads within 30 seconds | yes | |
| Test artifact sustained loads for 10 seconds or more. | yes | |
| Seat frame released from it's adjusted position? | n/a | |
| Seat frame or seat adjusters detach from the test platform/vehicle? | no | |
| Seat frame detaches from seat adjuster mechanism? | n/a | |
| Seat adjuster separates? | n/a | |


Pass/Fail PASS

| Notes: | | | | |
|--------|-----|--|--|--|
| | | | | |
| | | | | |
| | n/a | | | |

Work Order No.: 2107B4 Page 6 of 30


PRE-TEST PHOTOS







Work Order No.: 2107B4 Page 8 of 30

POST-TEST PHOTOS



Work Order No.: 2107B4 Page 9 of 30







Work Order No.: 2107B4 Page 12 of 30

FSTL

4545 W. Augusta Blvd.

| Customer [Company]: Fe Contact Name: Scott | act Test Request Work Order Form enton Mobility Date Generated: 6/10/2021 Fenton FSC Engineer (If Applicable): 16-499-7016 FSC Salesperson (If Applicable): scott@fentonmobility.com |)651 | | | |
|--|--|-----------------|--|--|--|
| What artifact will be tested? | 2pl, GO-ES foldaway, Spacesaver, CS | | | | |
| Postion of Artifact in Vehicle? | Row Two Curb Side - D | | | | |
| Specific Name of Vehicle (section)? | Ford Transit | | | | |
| What tests are requested? | Tests performed | | | | |
| | 5 Lower Anchors O FMVSS 222 Static Forward O FMVSS 222 Static Rearward | | | | |
| O FMVSS/CMVSS 207/210 O CMVSS 210 | | d | | | |
| O FMVSS 210 | | . | | | |
| 0 (11/35)(11/35) 210 | | | | | |
| O Other Prij | loads, both 207 & 210 (as called out in FMVSS). Reaching the final in 30 seconds and holding for 10 seconds. | | | | |
| Desired completion date? | | | | | |
| Is the test fixture a complete vehicle | e? • Yes • No | | | | |
| If 'Yes' is checked above, is the fixtu | ure drivable? O Yes O No | | | | |
| the overall dimensions of the test vehi- | traints of our laboratory facilities, we require that you provide a drawing to FSTL sho icle, all locations in the vehicle of the seats to be tested, the locations of any structu and the turning radius, if the vehicle is drivable. | wing ral tie | | | |
| When will the test fixture be sent? | 6/25/2021 | | | | |
| When will the test fixture arrive? | 6/25/2021 | | | | |
| What carrier will deliver the test fixtu | ure? Fenton | | | | |
| Testing Agency Performing Work: | : Freedman Seat Test lab | | | | |
| Testing Agency Address: | 4545 W Augusta Blvd. | | | | |
| Contact Person: | Ted Kolar / Dave O'Malley | | | | |
| Telephone: | 773-524-2440 | | | | |
| | fstl@freedmanseat.com | | | | |
| Manufacturer of Item to be Tested Attach an assembly drawing and include the assembly drawing number, if available. If no drawing exists, include a sketch describing the assembly. List the fastener types [bolts, washers, and nuts] and sizes, torque values well as specific amounts and locations to be used. Include wall and floor reinforcements Instructions for the specific mounting configuration to the test fixture must also be included [a drawing sketch is preferred]. | s, as e s. tion | | | | |
| Production Model Artifact: O Yes | No Production Built Artifact: Yes O No | | | | |

Work Order No.: 2107B4

| | | | | 4545 W. Aug | usta Blvd |
|--|---|---|---|--|--------------|
| Item to be tested is a: | O Unfinished Assembly - | e artifact is a complete up seat frame and base fram ct is a complete welded pion | e assembly without f | Chicago foam or cover | , IL 60651 |
| The test fixture is a: | O Complete New Vehicle O Complete Used Vehicle Full - Scale Vehicle Bo O Reduced - Scale Vehicl O Other - describe | e dy Section | | | |
| Reason for Te | st: N/A | | | | |
| said modifications at the preinforcement, hardware or Shall be provided by cust General Understanding of vehicle unusable. Customer Monitoring of The laboratory for the witness to maintain the confidentiality. | r supplies. Hardware us omer O As specified I f Tests: Tests are destr est: FSTL shall afford y ssing of this testing. Ho ty of other customers. | ructive and may damag you or your designated wever, FSTL may restr Will Monitor Testing? | to the test platform the the test vehicle s representative read to the viewing of c | structure, likely render sonable access to rele sertain items in these a | ing the test |
| This section is to be | ### 1921 | L personnel. Work Scheduled C Received By: | ompletion Date: | 12/31/2021 | |
| Date Request Reviewed: | 7/14/2021 | Reviewed By: | O OMally | | - |
| pon reviewing availability of resour | | FSTL is capable of perform | ning this test as reque | ested: | _ |
| his Test Request shall be performe | the reason being:ed by a competent subcontra | actor (ISO/IEC 17025 Accr | edited when Required | 1 | - |
| ame of Subcontractor: | | NIA | Chosen By: | O FSTL O Customer | n/a |
| chosen by FSTL, the reason being | O Unforeseen Reasons | S O Continuing Basis/Arra | ngement @ n/a | | |
| oon receiving a copy of this Review ate Reviewed Request was Submit | v the Customer has been no | tified in writing of the Testin | ng being Subcontracte | O Yes O | No 📵 n/a |
| Cu | stomer review signati | ure: Scott Fenton | | Date ###### | 1 |
| | SIGN | × A | | DATE 7/ | 19/21 |

FST


Information Data Sheet

Items with red asterisk or outlined in red are required fields. W Augusta Blvd Chicago, IL 60651

- Option 1: For a seat whose center of gravity is in a horizontal plane that is above the seat adjuster or that passes through any part of the adjuster, use, at the manufacturer's option, either **S5.1.1(b)** or pick **Option 2** below.
- Option 2: For a seat whose center of gravity is in a horizontal plane that is above the seat adjuster or that passes through any part of the adjuster, use, **S5.1.1(c)**.
- Option 3 [most common]: For a seat specified in Option 1 for which it is not physically possible to follow the procedure in S5.1.1(c), use **S5.1.1(b)**. [For all other seats whose seat back and seat bench are attached to the vehicle by the same attachments].
- Option 4: For a seat whose center of gravity is in a horizontal plane that is below the seat adjuster, use \$5.1.1(c).
- Option 5: FSTL to weigh and measure sample [must be fully built/upholstered]
- **⊘Option 6:** FSTL to use previous test data [previous Work Order 18∅3A2 and weight provided below]

with height of cq

To Be filled out by FSTL: Work Order No. Assigned: 2(\$\pi 7B4 \text{POSD}\$)



Weight of fully assembled seat system - W [Figure A & B] [Options 1, 2,3,4, & 6]

lbs. [Decimal number required]

Height of the center of gravity of the seat system from the floor - CG system [Figure A & B] [Options 1, 2,3,4, & 6]

14.81 inches [Decimal number required]

Work Order No.: 2107B4


Page 15 of 30

Test Setup Review Checklist

FSTL

4545 W. Augusta Blvd. Chicago. IL 60651

| NOT | | | oago, iz oooo i |
|----------------------|--|---|----------------------|
| OK APPLY | | | |
| | _ Artifact is built to print [welds, gussets, bracke | ets, accessories, etc.] | |
| V | Artifact has correct fasteners, torques, and fa- | stener engagement. | |
| | The correct fasteners and their quantity/locati or vehicle section. | on are used to connect the artifact to the | test platform |
| | The artifact is adjusted correctly and engaged | I [back angle, pedestal height, slide track | position, etc.] |
| | Testing fixtures placed correctly. [body and sh | noulder blocks, SFAD, pushing bars, belt | routing, etc.] |
| / | Artifact is setup according to supplied setup d | Irawings. | - 1 |
| V | The target loads and holding times are correct | t. 3,000 #5 LAP - SHLD. | + 20x(m) |
| / | The same and 15 car | | |
| / | The angles of force application are correct. | 100725 | |
| X | The target accelerations, peak to peak displa | cement, frequencies, time duration, etc. a | are correct and that |
| | the test fixture/test artifact center of mass local [specific to Vibration tests] | ated over the center of the vibration table | |
| Additional Notes | | gy CosTONER - | |
| | - N/a | | |
| to be correct. Corre | nave reviewed the seat assembly to be teste ecting information gathered on FSTL Record ne error, provide the correction, and then init | s requires the originator to correct the | |
| Seat Designer/Pro | oject Engineer [sign] | Date: | 92-31 |
| Seat Designer/Pro | oject Engineer [print] | | |
| FSTL: | Setup Personnel & OMally | Date: 7/ | 22/2021 |
| | t be conducted without a copy of this form siner or project engineer. | gned, dated, and completed by the de | esignated |
| Tes | st Performed By: | Date: 7/ | 22/2021 |
| Tes | st Witnessed By: | J(A Date: | MA |
| Pre-Tes | st option: Simplified Test Report: Yes Note that Photos By: Option st Photos By: Digital Set Verification 1: Digital Set | | ompletness, etc. |



Work Order No.: 2107B4 Page 17 of 30

26400

NOT TO BE USED, DISCLOSED OR REPRODUCED WITHOUT PERMISSION. PROPERTY OF THE FREEDMAN SEATING COMPANY.

- 1) ASSEMBLED SEAT WEIGHT IS 105 LBS.
- 2) SEE DRAWING 25890 FOR PART# AND COLOR OF THE GRAB HANDLE.
- 3) CAUTION: IT IS NOT POSSIBLE TO TEST EVERY PERMUTATION OF SEAT WIDTH, ACCESSORY COMBINATION, SEAT HEIGHT, POSITION IN VEHICLE, OR SEAT BELT REQUIREMENT. FOR THIS REASON, IT MUST BE EMPHASIZED THAT COMPLIANCE CAN NOT BE ASSUMED WHERE THERE IS ANY DEVIATION FROM THE STANDARD SUPPLY OR ASSEMBLY METHOD. ADDITIONALLY, THE ADVANTAGES OF THIS PRODUCT MAY BE LOST IF INSUFFICIENT CONSIDERATION IS GIVEN TO THE METHOD OF INSTALLATION OF SEAT TO VEHICLE.
- 4) FULL FEDERAL MOTOR VEHICLE SAFETY STANDARDS AND REGULATIONS COMPLIANCE CAN ONLY BE ACHIEVED THROUGH VEHICLE TESTING.
- 5) PRODUCT IMPROVEMENT MAY AFFECT SPECIFICATIONS.
- 6) INCLUDE ONE COPY OF #15361 WITH EVERY SEAT SET.

N ADD 99015,71728, REMOVE 99266, UPDATE 120396 QTY LH 2/19 7420

M ADDED QTY TO 99324

J ADD 99266 & 99063

K REPLACED 56602 WITH 27080 & 27082;

REPLACED 56600 WITH 27078 & 27073

Description of Change

L REMOVE 70900

7) FOR THE RESTRAINT SYSTEM TO WORK, SEAT FRAME PLANE C MUST BE PARALLEL TO ZERO H PLANE (HORIZONTAL FLOOR).

| ITEM | QTY | PART # | DESCRIPTION |
|------|-----|-------------|---|
| 1 | 1 | SEE CHART 1 | WELDMENT, SEATBASE, 3PT, CS |
| 2 | 1 | 26410 | WELDMENT, FLOORMOUNT, 3PT, CS |
| 3 | 1 | SEE CHART 1 | WELDMENT, SEAT BACK, 3PT, CS |
| 4 | 1 | 26414 | WELDMENT, TRUSS, 3PT |
| 5 | 1 | 26470 | ROD, CONTROL, 3PT |
| 6 | 1 | 26473 | TUBE, TRUNION, 3PT |
| 7 | 1 | 26472 | TUBE, PIVOT, LOWER |
| 8 | 1 | 38708 | WELDMENT, PLATE, SIDE, AISLE, 3PT, CS |
| 9 | 1 | 38704 | WELDMENT, PLATE, SIDE, WALL, 3PT, CS |
| 10 | 1 | 26468 | PLATE, HANDLE, 3PT, CS |
| 11 | 2 | 26466 | PLATE, LOCK, CAM, 3PT |
| 12 | 1 | 31347 | FLEX-O-LATOR, BV |
| 13 | 12 | 53962 | HOOK, U, OYSTER |
| 14 | 12 | 55859 | SPRING, FLEX-0-LATOR, BV |
| 15 | 1 | 99500 | 8-32 x 1 1/4 PHILLIPS PAN HEAD MACHINE SCREW, ZP |
| 16 | 1 | 99113 | SPLIT COTTER PIN, 3/16 X 2, ZP |
| 17 | 1 | 21090 | WELDMENT, LOCK MECH. |
| 18 | 1 | 21091 | WELDMENT, LOCK MECH. |
| 19 | 1 | 21107 | SPRING, RETURN |
| 20 | 1 | 21108 | SPRING, RETURN |
| 21 | 6 | 9422301 | 1/2-13 PREV TORQUE HEX CONICAL TOP LOCKNUT, GR8, ZP |
| 22 | 2 | 180124 | 3/8 - 16 X 1 1/4 HEX HEAD BOLT, GR 5, ZP |
| 23 | 10 | 56408 | BLACK SILICONE ADHESIVE |
| 24 | 2 | 55965 | 3/8 I.D. X 1/2 LG. BLACK PLASTIC CAP |
| 25 | 2 | 21214 | RED PLASTIC COVER RECTANGLE |
| 26 | 1 | 21210 | GAS SPRING |
| 27 | 2 | 21205 | FITTINGS, BALL END |
| 28 | 3 | 9422275 | 5/16 LOCK NUT, PREV TORQ, GR 5, ZP |
| 29 | 1 | 213 | RED PLASTIC COVER, 1/2 X 1/4 X 1 |
| 30 | 3 | 180122 | 3/8 - 16 X 1 HEX HEAD BOLT, GR 5, ZP |
| 31 | 1 | 180128 | 3/8 - 16 X 1 3/4 HEX HEAD BOLT, GR 5, ZP |
| 32 | 1 | 99334 | 7/16-20 X 1 1/4 HEX HEAD BOLT, GR 8, BLACK OXIDE |
| 3332 | 202 | 21 | |

RECEIVED

By Dave OMalley at 2:08 pm, Jul 13, 2021

JL 8/18 7039 DN 10/14 4288

SC 11/11 2134

EJ 06/11 1914

ECN # Level

By Date

36 10

7/16 - 20 PREV TORQUE HEX CONICAL TOP LCKNUT, GR C, BO

Tolerances Unless Otherwise Specified

FRACTION 1/X ±1/32"

DECIMAL .XX ±0.02" .XXX ±0.005"

ANGULAR ±1°

SC 7/10 1343

Date ECN :

| | | | CH/ | ART 1 |
|--|-----|-----|--------|---|
| | MEM | QTY | PART # | DESCRIPTION |
| ASSY, 3PT FOLDAWAY, 2PL, CS | 1 | 1 | 26402 | WELDMENT, SEATBASE, 3PT, CS |
| PART# 26400 | 3 | 1 | 26408 | WELDMENT, SEAT BACK, 3PT, MID-HI, CS |
| 1 AKI# 20100 | 66 | 1 | 26510 | COVER, 3PT FOLDAWAY, BACK, MID-HI, CS |
| | 67 | 1 | 26542 | COVER, 3PT FOLDAWAY, SEATBASE, CS |
| | 1 | 1 | 26402 | WELDMENT, SEATBASE, 3PT, CS |
| ASSY, 3PT FOLDAWAY, 2PL, CMPAN, CS | 3 | 1 | 39572 | WELDMENT, SEAT BACK, 3PT, CMPAN, MID-HI, CS |
| PART# 39568 | 66 | 1 | 28337 | COVER, 3PT FOLDAWAY, CMPAN, BACK, MID-HI, CS |
| ,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,, | | 1 | 26542 | COVER, 3PT FOLDAWAY, SEATBASE, CS |
| | 1 | 1 | 26534 | WELDMENT, SEATBASE, 3PT, CRS, CS |
| ASSY, 3PT FOLDAWAY, CRS, 2PL, CS | 3 | 1 | 26538 | WELDMENT, SEAT BACK, 3PT, MID-HI, CRS, CS |
| PART# 26526 | 66 | 1 | 26546 | COVER, 3PT FOLDAWAY, BACK, MID-HI, CRS, CS |
| | 67 | 1 | 26544 | COVER, 3PT FOLDAWAY, SEATBASE, CRS, CS |
| | 1 | 1 | 26534 | WELDMENT, SEATBASE, 3PT, CRS, CS |
| ACCY ZOT FOLDAWAY ODG ODL ONDAN OC | 3 | 1 | 39574 | WELDMENT, SEAT BACK, 3PT, CMPAN, MID-HI, CRS, CS |
| ASSY, 3PT FOLDAWAY, CRS, 2PL, CMPAN, CS PART# 39570 | 66 | 1 | 28365 | COVER, 3PT FOLDAWAY, CMPAN, BACK, MID-HI, CRS, CS |
| PARI# 393/U | 67 | 1 | 26544 | COVER, 3PT FOLDAWAY, SEATBASE, CRS, CS |

H ADD 70900; DELETE 120395, 120394

(12 29/32) WAS 12 29/32; (6 9/32) WAS 6 9/32

Description of Change

MODIFY 21090 & 21091; 99530 WAS 99501

180020, 26485, & 31788

| | | 96 1 2/0/3 F | RS,ASSY,BUCKLE,3P1,FLDWY,WEB | ,HC | |
|-----------------|----------------|------------------------|------------------------------|---|--|
| | | | | PAGE 1 OF 5 | |
| Material: | | Freedman Seating Co. | | 4545 W. Augusta Blvd Chicago, IL 60651 | |
| Specifications: | | Part Name ASSY, 3PT FO | OLDAWAY, 2PL, CS | | |
| Drawn by: RW | Date: 09/27/04 | DO NOT SCALE DRAWING | Drawing No. 26400 | Rev. | |

| | ITEM | QTY | PART # | DESCRIPTION |
|-----|-----------------|----------|-------------|---|
| | 37 | 4 | 9422277 | 3/8-16 PREV TORQUE LOCK NUT, GR5, ZP |
| | 38 | 2 | 454979 | 7/16 - 20 X 2 1/2 HEX HEAD BOLT, GR 8, ZP |
| | 39 | 1 | 99474 | 7/16 - 20 X 1 1/4 X 3/4 SPECIAL THREAD, HHCS, G8, B/O |
| | 40 | 1 | 455002 | 1/2 - 13 X 2 1/2 HEX HEAD BOLT, GR 8, ZP |
| | 41 | 1 | 427565 | 1/2 - 13 X 1 3/4 HEX HEAD BOLT, GR 8, ZP |
| (0) | 42 | 5 | 120396 | 1/2 SAE FLATWASHER, ZP |
| | 43 | | | |
| - 1 | 44 | 4 | 99240 | #8 X 3/4 SCREW, TEK, ROUND, PHILL, BLACK |
| - 1 | 45 | 1 | | |
| - 1 | 46 | 3 | 120392 | 1/4 SAE FLATWASHER, ZP |
| - 1 | 47 | | | · |
| 1 | 48 | | | |
| | 49 | 2 | 99332 | SCREW, CAP, SOKT, SHOULDER, 3/8 X 3/8 LONG |
| - 1 | 50 | 1 | 38698 | PLATE, DUMP LOCK, 3PT |
| | 51 | N/A | 56383 | THREAD LOCKER, VIBRA-TITE, RED |
| | 52 | 1 | 26490 | SPRING, 3PT, HANDLE |
| | 53 | <u> </u> | 20100 | OF MINO, OF 1, THATBLE |
| - 1 | 54 | | | |
| | 55 | | | |
| | 56 | 2 | SEE NOTE 2 | GRAB HANDLE |
| | 57 | 1 | 26429 | WELDMENT, TRUSS LEG LOCK, 3PT |
| | | - | 20429 | WELDMENT, TRUSS LEG LOCK, JPT |
| | <u>58</u> 59 | \vdash | | |
| | 60 | | | |
| | | - | 00554 | FOUL CEATRACE 7DT FOLDAWAY OC |
| | 61 | 1 | 26551 | FOAM, SEATBASE, 3PT FOLDAWAY, CS |
| | 62 | | | |
| | 63 | | | |
| | 64 | | | |
| | 65 | | | |
| | 66 | 1 | SEE CHART 1 | COVER, 3PT FOLDAWAY, BACK, MID-HI, CS |
| | 67 | 1 | SEE CHART 1 | |
| | 68 | 1 | 28585 | DUMP COVER, AISLE SIDE, CS, 3PT |
| | 69 | 1 | 28586 | DUMP COVER, WALL SIDE, CS, 3PT |
| | 70 | 4 | 56618 | NYLINER BEARING |
| | 71 | | | |
| | 72 | | | |
| | 73 | | | |
| | 74 | 3 | 99118 | BELLVILLE WASHER, 1/2 ID X 1 OD |
| | 75 | 2 | 55988 | BUMPER PAD, CROSS LINK POLETHYLENE 1/8 X 1 X 2 5/8 |
| | 76 | 1 | 31470 | VINYL BLACK, 33 1/2 X 18 |
| | 77 | 2 | 55253 | BLACK PLASTIC CAP, PLUG |
| | 78 | 1 | 55713 | LABEL, ADHESV, SEATBACK, "CAUTION" 3"L X 3/4" W |
| | 79 | 2 | 56589 | END CAP, TRUSS, FOLDAWAY |
| | 80 | | | |
| | 81 | | | |
| | 82 | 11 | 99324 | 7/16" FLATWASHER, SAE BLACK OXIDE |
| | 83 | 1 | 15361 | INSTRUCTIONS, SWITCHABLE ELR |
| | 84 | | | |
| | 85 | 1 | 56658 | INSTRUCTIONS, 3PT FOLDAWAY |
| (N) | 86 | 2 | 99015 | 7/16", WASHER, FLAT, USS, G8, ZP, YEL |
| - | 87 | 5 | 99195 | 1/4" - 20 X 3/4", SCREW, SOCKET, BTN HD, FLANGE |
| - 1 | 88 | 1 | 99530 | NUT, ACORN, CENTER-LOCK, 8-32, GR-A, ZP |
| - 1 | 89 | 1 | 51126474 | FOAM, MID-HI BACK, REAR FACE, 3PT FLDWY |
| ı | 90 | 1 | 51126475 | FOAM, MID-HI BACK, REAR FACE, 3PT FLDWY FOAM, MID-HI BACK, FRONT FACE, 3PT FLDWY |
| (N) | 91 | 2 | 71728 | SCREW, BUTN HD, 1/4-20 X 3/4, ZP |
| | 92 | 4 | 99063 | 1/4" NYLON FLAT WASHER |
| - 1 | 93 | 1 | 27080 | RS,ASSY,RTCTR,3PT,FLDWY,CNTR,RH |
| - 1 | 94 | 1 | 27082 | RS,ASSY,BUCKLE,3PT,FLDWY,STEM,HC |
| - 1 | 95 | 1 | 27078 | RS,ASSY,RTCTR,3PT,FLDWY,WL,HC,RH |
| - 1 | 96 | 1 | 27073 | RS,ASSY,BUCKLE,3PT,FLDWY,WEB,HC |
| | | | | |
| | | | | DACE 1 OF 5 |

26400

NOT TO BE USED, DISCLOSED OR REPRODUCED WITHOUT PERMISSION.
PROPERTY OF THE FREEDMAN SEATING COMPANY.

ASSEMBLY PROCEDURE

- 1) REMOVE WELD SPLATTER IN TRUSS SLIDER.
- 2) ATTACH SEATBASE TO FLOORMOUNT BY SLIDING TRUNION TUBE (26473) THROUGH SEATBASE BEARING. FASTEN USING 8-32 x 1 1/4 PHILLIPS PAN HEAD SCREW & 8-32 ACORN NUT (APPLY RED LOCTITE).
- 3) ENGAGE TRUSS IN TRUSS SLIDER CHANNELS OF SEATBASE AND SECURE AT BOTTOM WITH PIVOT TUBE, (26472) AND BEARINGS. ALIGN HOLES FOR SPRING PIN. CHECK FOR UPRIGHT VERTICAL POSITION OF SEATBASE.
- 4) ATTACH GAS SPRING END FITTING ONTO SEATBASE WITH 5/16 18 LOCK NUT. ASSEMBLE TWO (2) 3/8 16 X 1 1/4 LEVELING SCREWS TO END OF TRUSS SLIDER. ATTACH TWO (2) LOCKS, WITH SPRINGS, USING 1/2 13 WASHER HEAD LOCK NUTS.
- 5) FASTEN GAS SPRING END FITTING TO FLOORMOUNT USING 5/16 18 LOCK NUT.
- 6) "POP" THE TUBE END OF THE GAS SPRING ONTO THE FITTING ON THE SEATBASE. USING THE "LEVER ACTION FORCE TOOL," WITH THE SEATBASE IN THE UP POSITION, "POP" THE ROD END ONTO THE FITTING ON THE FLOORMOUNT. GAS SPRING IS MOUNTED WITH THE ROD END DOWN.
- 7) ATTACH FLEX-O-LATOR TO SEATBASE WITH TWELVE (12) SPRINGS AND TWELVE (12) OYSTER CLIPS. SEE PAGE 3 OF DRAWING FOR ORIENTATION AND LOCATION OF SPRINGS AND OYSTER CLIPS.
- 8) ASSEMBLE DUMP MECHANISM BY ATTACHING HANDLE (26468) AND CONTROL ROD (26470) TO LOCK (26466) WITH 1/4 20 BOLT AND LOCTITE. LEAVE LOOSE ENOUGH TO ROTATE. FEED ROD THROUGH REAR SEATBASE TUBE AND ATTACH LOCK (26466) TO CONTROL ROD WITH 1/4 20 BOLT AND LOCTITE. GREASE BOTH LOCKS AT PIVOT LOCATION. BOLT ASSEMBLY TO REAR TUBE WITH 1/2 13 BOLTS AND NUTS AS SHOWN ON PAGE 4. CHECK TO VERIFY PROPER EASY ROTATION.
- 9) ATTACH SIDE PLATE WELDMENTS (38708 AND 38704) TO SEATBASE USING 3/8 16 BOLTS, WASHERS AND NUTS. CONNECT HANDLE SPRING 26490 TO HANDLE AND AISLE SIDE PLATE. VERIFY OPERATION.
- 10) ATTACH SEATBACK TO SEATBASE SIDE PLATES WITH 7/16 20 BOLTS, WASHERS, AND NUTS. ATTACH PART (26495) TO SEATBACK. ADD FLAT SPRING TO SEATBACK USING BOLT 99330. VERIFY PROPER BACK OPERATION.
- 11) ADD DUMP LOCK 38698 TO SEAT USING BOLT 99332 WITH 5/16-18 NUT AND LOCTITE.
- 12) CHECK FOR OPERATION: UP/DOWN LOCKS, TRUSS SLIDING, DUMP MECHANISM, GAS SPRING FORCE, WELDS ON PULL DOWN WIRES AND MOTION OF SEATBACK.
- 13) CHECK THAT SEAT BACK CHUCK (MOVEMENT) IS LESS THAN 1' WHEN A REASONABLE LOAD IS APPLIED TO SEAT BACK.
- 14) PREPARE SEAT FOAM BY APPLYING TICKING TO BACKSIDE OF SEATBACK AND SEATBASE FOAM.
- 15) ATTACH SEATBACK FOAM ONTO FRAME ONLY ON TOP AND CENTER TUBES.
- 16) ATTACH RETRACTORS TO SEATBACK USING 7/16 20 NUTS. VERIFY PROPER BELT OPERATION.
- 17) ADD TRIM COVERS TO SEAT. CUT FABRIC ON SEATBACK WHERE INDICATED. ATTACH BEZEL TO SEATBACK USING SCREWS (99240). ATTACH BUCKLES USING 7/16 20 BOLTS, WASHERS, AND NUTS.
- 18) ADD DUMP COVERS, HANDLE COVERS, 3PT INSTRUCTIONS, SIDE BUCKLE AND TRUSS LEG LOCK COMPONENTS.
- 19) VERIFY PROPER OPERATION OF BELTS AND BUCKLES.

RECEIVED

By Dave OMalley at 2:08 pm, Jul 13, 2021


| | REMOVE 70900 | DN | 10/14 | 4288 | _ | ADD 70900; DELETE 120395, 120394 | | | | 7 7 | Tolerances Unless Otherwise Specified | Material: | | Freedman Seating Co. | 4545 W. Aug |
|----|------------------------------------|----|-------|-------|------|--|----|------|-------|-------|--|-------------------------|----------------|--|---------------|
| | REPLACED 56602 WITH 27080 & 27082; | 4 | | 1 | + | 180020, 26485, & 31788 | ╄ | | _ | J гра | PACTION 1/X ±1/32" | | | S | Chicago, IL 6 |
| | REPLACED 56600 WITH 27078 & 27073 | SC | 11/11 | 2134 | | (12 29/32) WAS 12 29/32; (6 9/32) WAS 6 9/32 | _ | | | | CIMAL .XX ±0.02" | Specifications: | | Part Name ASSY, 3PT FOLDAWAY, 2PL, CS | |
| _J | ADD 99266 & 99063 | EJ | 06/11 | 1914 | | MODIFY 21090 & 21091; 99530 WAS 99501 | SC | 7/10 | 1343 | | .XXX ±0.005" | , | | ASSI, SFI TOLDAWAI, ZFL, CS | |
| Re | Description of Change | Bv | Date | FCN : | Rev. | . Description of Change | Bv | Date | FCN 4 | AN AN | NGULAR ±1° | Drawn by: _{RW} | Date: 09/27/04 | DO NOT SCALE DRAWING Drawing No. 26400 | Rev. |


PAGE 2 OF 5

Work Order No.: 2107B4 Page 19 of 30

26400

NOT TO BE USED, DISCLOSED OR REPRODUCED WITHOUT PERMISSION.
PROPERTY OF THE FREEDMAN SEATING COMPANY.






ASSY, 3PT FOLDAWAY, 2PL, CS IS SHOWN

RECEIVED

By Dave OMalley at 2:08 pm, Jul 13, 2021



| N | ADD 99015,71728, REMOVE 99266, UPDATE 120396 QTY | ᄖ | 2/19 | 1 | 420 | | | | | | | | | | | PAGE 3 OF 5 |
|------|--|----|------|--------------|------|---------------|--|----|------|------|----------|--------------------------------|-----------------|----------------|--|----------------------|
| M | ADDED QTY TO 99324 | JL | 8/18 | <u>: 1</u> : | 039 | | | | | | | | | | | 17.0E 0 01 0 |
| L | REMOVE 70900 | DN | 10/ | 14 4 | 288 | н | ADD 70900; DELETE 120395, 120394 | | | | Tolero | inces Unless wise Specified | Material: | | Formal Continue Co | 4545 W. Augusta Blvd |
| K | REPLACED 56602 WITH 27080 & 27082; | | | | | | 180020, 26485, & 31788 | | | | | • | | | Freedman Seating Co. | Chicago, IL 60651 |
| | REPLACED 56600 WITH 27078 & 27073 | SC | 11/ | 11 : | 134 | | (12 29/32) WAS 12 29/32; (6 9/32) WAS 6 9/32 | | | | | 1 1/X ±1/32" .XX ±0.02" | Specifications: | | Part Name ACCV ZDT FOLDAWAY 2DL CC | |
| J | ADD 99266 & 99063 | EJ | 06/ | I1 · | 914 | | MODIFY 21090 & 21091; 99530 WAS 99501 | SC | 7/10 | 1343 | DECIMAL | .XXX ±0.005* | - | | rath warme ASSY, 3PT FOLDAWAY, 2PL, CS | |
| Rev. | Description of Change | Ву | Date | e E | CN # | Rev. Level | Description of Change | Ву | Date | ECN | # ANGULA | R ±1° | Drawn by: RW | Date: 09/27/04 | DO NOT SCALE DRAWING Drawing No. 26400 | Rev. |
| | | | | | | | • | • | | | | | | | | |

Work Order No.: 2107B4 Page 20 of 30

26400

NOT TO BE USED, DISCLOSED OR REPRODUCED WITHOUT PERMISSION. PROPERTY OF THE FREEDMAN SEATING COMPANY.

RECEIVED

By Dave OMalley at 2:08 pm, Jul 13, 2021

NOTE: DETAILS & SPECIFICATIONS ARE SHOWN ON DRAWING 26500

N ADD 99015,71728, REMOVE 99266, UPDATE 120396 QTV LH 2/19 7420


M ADDED QTV TO 99324 JL 8/18 7039

1 0510005 70000 DN 10/14 4388 H


PAGE 4 OF 5

| | l A | ADDED QTY TO 99324 | ᄮ | 8/18 | 7039 | • | | | | | | | | | | |
|----------|-----------|------------------------------------|----|-------|------|-------|--|----|------|-------|-------|--------------------------------------|-----------------|----------------|--|----------------------|
| L | R | REMOVE 70900 | DN | 10/14 | 428 | 3 Н | ADD 70900; DELETE 120395, 120394 | | | | Tol | lerances Unless herwise Specified | Material: | | Formados and Continue Co | 4545 W. Augusta Blvd |
| K | R | REPLACED 56602 WITH 27080 & 27082; | | | | | 180020, 26485, & 31788 | | | | 1 | | | | Freedman Seating Co. | Chicago, IL 60651 |
| | R | REPLACED 56600 WITH 27078 & 27073 | sc | 11/11 | 213 | ı | (12 29/32) WAS 12 29/32; (6 9/32) WAS 6 9/32 | | | | | TION 1/X ±1/32" MAL .XX ±0.02" | Specifications: | | Part Name ACCV ZDT FOLDAWAY 2DL CC | ` |
| J | A | ADD 99266 & 99063 | EJ | 06/11 | 1914 | ١ | MODIFY 21090 & 21091; 99530 WAS 99501 | SC | 7/10 | 1343 | DECIN | .XXX ±0.005" | | | FOLDAWAY, 2PL, CS |) |
| Re Le | v. ⁄el | Description of Change | Ву | Date | ECN | # Rev | Description of Change | Ву | Date | ECN ; | | JLAR ±1° | Drawn by: RW | Date: 09/27/04 | DO NOT SCALE DRAWING Drawing No. 26400 | Rev. |

Work Order No.: 2107B4 Page 21 of 30



Work Order No.: 2107B4 Page 22 of 30



Work Order No.: 2107B4 Page 23 of 30



SCOPE OF ACCREDITATION TO ISO/IEC 17025:2017

FSTL 4545 W. Augusta Blvd. Chicago, IL 60651

Phone: (773) 524 2440 Dave Klopp

MECHANICAL

Certificate Number: 2324.01 Valid To: June 30, 2023

In recognition of the successful completion of the A2LA evaluation process, accreditation is granted to this laboratory to perform the following types of tests on transportation seating products:

Test Test Methods

Child Restraint Anchorage Systems*: CMVSS 210.1, 210.2; FMVSS 571.225;

Tension Up to 9000 lbs FSTL Tension Test Procedures LP03, LP25, LP28

Compression*: FSTL Compression Test Procedures LP04, LP23, LP25,

Up to 5000 lbs LP28

Cyclic Fatigue*: FSTL Fatigue Test Procedures LP02, LP24

(100 to 250) lbs Up to 12 in Up to 10 Hz

Devices for Use in Defining and Measuring

Vehicle Seating Accommodation – Hpoint*:

Displacement Up to 36 in

SAE J826 (November 2008)

Displacement*: FSTL Displacement Test Procedures LP01 Up to 36 in

Seat Belt Assembly Anchorages*: CMVSS 210; FMVSS 571.210;

Tension Up to 9000 lbs FSTL Tension Test Procedures LP03, LP25, LP28

Seating Systems*: FMVSS 571.207; CMVSS 207;

Tension (0 to 9000) lbs FSTL Tension Test Procedures LP03, LP25, LP28

Work Order No.: 2107B4 Page 24 of 30

FMVSS 571.222; CMVSS 222

School Bus Passenger Seating and Crash Protection*:

Tension Up to 9000 lbs Compression Up to 5000 lbs Displacement Up to 36 in Acceleration (0 to 1,000) g

Seat performance forward and reward. Seat cushion latching and retention. Quasi-static test of compartmentalization and Type 2 seat belt performance. Impact zone requirements (Head protection Zone. Leg protection zone.)

Page 2 of 2

^{*}Also using similar test methods based on the parameters listed above.

Work Order No.: 2107B4 Page 25 of 30



Accredited Laboratory

A2LA has accredited

FSTL Chicago, IL

for technical competence in the field of

Mechanical Testing

This laboratory is accredited in accordance with the recognized International Standard ISO/IEC 17025:2017 General requirements for the competence of testing and calibration laboratories. This accreditation demonstrates technical competence for a defined scope and the operation of a laboratory quality management system (refer to joint ISO-ILAC-IAF Communiqué dated April 2017).



Presented this 1st day of July 2021.

Vice President, Accreditation Services
For the Accreditation Council
Certificate Number 2324.01

Valid to June 30, 2023

21081-21





Calibration Certificate

1490 W. Bernard Dr. Suite E Addison, IL 60101

P: (630)613-9350 www.GreatLakesCalibration.com

Your Guide To Quality Control

This calibration was performed on-site at the address below for:

FSTL

4545 W AUGUSTA BLVD CHICAGO, IL 60804

Date of Calibration:

Purchase Order:

Monday, February 8, 2021

Certificate #:

Calibration Interval: Calibration Due Date:

2/8/2022 Y72041

12 - Months

Condition Received: Condition Returned:

Within Tolerance Within Tolerance

Equipment Information

Manufacturer: INTERFACE Model Number: SSM2-AF-10K Serial Number: 1137893 LC-001 Asset ID: MECH-001 Work instruction:

6

ASTM E4-2020

External Cell Serial: External Cell Asset ID: **Calibration Direction:**

Calibration Method:

External Cell Mfg: N/A External Cell Model: N/A N/A N/A TENSION ASTM E-74 LOAD CELL Calibration Device:

Software Version: Temp / Hum: Technician:

Display Mfg:

Display Model #:

Display Serial #:

N/A DAQ SYS1 V1.1.0.0 73.2°F / 28%RH

N/A

N/A

Abelardo Garcia 1 of 1 Page:

Description: 9,000-lb Load Cell

Revision:

Specification:


The data contained within this report pertains only to the item(s) as described above. This report shall not be reproduced except in full without the prior written approval of Great Lakes Calibration, Inc. The calibration was performed in accordance with the most current revision of work instruction MECH-001 (which is based off the requirements of ASTM E-4) and the governing specification listed above and is compliant with ISO/IEC 17025:2017, ANS/NCSL Z540-1-1994, ISO9000, and TS-16949.

FOLLOW THE FORCE

The calibration device(s) used is either a Class-A temperature Compensated load cell that has been certified by an accredited laboratory in accordance with ASTM E-74 or certified Dead weights.

| | | | | | Calibration D | Data (TENSION) | | | | | | |
|------------------|--------------------------------|--------------------|------------------------|------------------------------|-----------------------------------|-----------------------|--------------------------------|--------------------------|-------------------|---------------------|-----------|------|
| | Certified Range: Capacity: | | В | | Max Error (%): 0.38% units: LB | | Tolerance (+/-): Indicator: | | Ch | neck Cal / Shunt: | N/A | |
| Reading (%FS) | Nominal-UUT Indication (LB) | Resolution (LB) | Run-1 As Found (LB) | Run-1 As Found Error (LB) | Run-1 As Found Error (%) | Run-2 As Left (LB) | Run-2 As Left Error (LB) | Max Error As Left (%) | Repeatability (%) | Uncertainty (LB) | Pass/Fail | Eqpt |
| 0.0% | return to zero | 0.010 | 0.276 | -0.276 | 0.00% | 0.130 | 0.000 | 0.00% | | 2.9E-03 | PASS | Α |
| 2.2% | 200.000 | 0.010 | 200.760 | -0.760 | -0.38% | 200.662 | -0.662 | -0.38% | 0.05% | 6.8E-01 | PASS | Α |
| 4.4% | 400.000 | 0.010 | 398.827 | 1.173 | 0.29% | 399.120 | 0.880 | 0.29% | -0.07% | 1.5E+00 | PASS | Α |
| 6.7% | 600.000 | 0.010 | 597.880 | 2.120 | 0.35% | 597.724 | 2.276 | 0.38% | 0.03% | 1.9E+00 | PASS | Α |
| 8.9% | 800.000 | 0.010 | 797.230 | 2.770 | 0.35% | 797.432 | 2.568 | 0.35% | -0.03% | 2.5E+00 | PASS | Α |
| 11.1% | 1,000.000 | 0.010 | 998.320 | 1.680 | 0.17% | 998.109 | 1.891 | 0.19% | 0.02% | 3.1E+00 | PASS | Α |
| 22.2% | 2,000.000 | 0.010 | 1,998.423 | 1.577 | 0.08% | 1,998.280 | 1.720 | 0.09% | 0.01% | 5.9E+00 | PASS | Α |
| 44.4% | 4,000.000 | 0.010 | 3,994.363 | 5.637 | 0.14% | 3,994.587 | 5.413 | 0.14% | -0.01% | 1.2E+01 | PASS | Α |
| 66.7% | 6,000.000 | 0.010 | 5,990.625 | 9.375 | 0.16% | 5,991.427 | 8.573 | 0.16% | -0.01% | 1.8E+01 | PASS | Α |
| 100.0% | 9,000.000 | 0.010 | 8,988.250 | 11.750 | 0.13% | 8,989.916 | 10.084 | 0.13% | -0.02% | 2.8E+01 | PASS | А |
| | | | | | | | | | | | | |

Reported uncertainty values have been estimated at the 95% confidence level with a coverage factor of K=2 and are a combination of the reference standard uncertainty, the UUT resolution, and the UUT repeatability. Uncertainties are reported but not combined with the UUT error for the determination of the "PASS/FAIL" status.



All applicable clauses of ASTM E4 have been met unless otherwise noted below

8/29/2018

3.1.12 (The Resolution is stated as 1/2 the fluctuation of the indicator)

REV-04.05

10.1 (Readings taken below 200 times the resolution)

Adjustments Were Made

10.5 (Does not return to zero within 30-seconds) 17.1 (Error or repeatability greater than 1.0%)

7.3 (Interchangeability established) Annex A1 (Verified outside of testing machine) Calibration Standards Used: All verification devices used are traceable to the National Institute of Standards and Technology (NIST)

Description: Cal Date Class-A Ten (lb) Class-A Comp(lb) Calibrated By: ID#: Cal Due Eqpt Used Manufacturer: MOREHOUSE 10-kip Class-A Load Cell Temperature-Humidity Meter M-1368 T-043 09/17/2019 01/11/2021 09/17/2021 01/11/2022 GREAT LAKES CALIBRATION

QA Approval - Marya Black (QM)

Customer Approval

Print Date: 2/16/2021 14:14

Force-1





Calibration Certificate

21081-7

Certificate #:

1490 W. Bernard Dr. Suite E Addison, IL 60101 P: (630)613-9350

Addison, IL 60101 www.GreatLakesCalibration.com

Your Guide To Quality Control

This calibration was performed on-site at the address below for:

FSTL 4545 W AUGUSTA BLVD CHICAGO, IL 60804 Date of Calibration: Monday, February 8, 2021

Calibration Interval: 12 - Months
Calibration Due Date: 2/8/2022
Purchase Order: Y72041
Condition Received: Within Tolerance
Condition Returned: Within Tolerance

Equipment Information

Manufacturer: RICE LAKE N/A N/A External Cell Mfg: Display Mfg: Model Number: RL20001-T10-15K External Cell Model: N/A Display Model #: N/A Serial Number: 21573750 External Cell Serial: N/A Display Serial #: N/A Asset ID: LC-002 External Cell Asset ID: N/A Software Version: DAQ SYS1 V1.1.0.0 MECH-001 **Calibration Direction: TENSION** 72.7°F / 27%RH Work instruction: Temp / Hum: Revision: 6 Calibration Device: ASTM E-74 LOAD CELL Technician: Abelardo Garcia Specification: ASTM E4-2020 Calibration Method: FOLLOW THE FORCE Page: 1 of 1 Description: 9,000-lb Load Cell

The data contained within this report pertains only to the item(s) as described above. This report shall not be reproduced except in full without the prior written approval of Great Lakes Calibration, Inc.

The calibration was performed in accordance with the most current revision of work instruction MECH-001 (which is based off the requirements of ASTM E-4) and the governing specification listed above and is compliant with ISO/IEC 17025:2017,

ANS/NCSL Z540-1-1994, ISO9000, and TS-16949.

The calibration device(s) used is either a Class-A temperature Compensated load cell that has been certified by an accredited laboratory in accordance with ASTM E-74 or certified Dead weights.

| | | | | | Calibratio | on Data (TENSION) | | | | | | |
|------------------|--------------------------------|--------------------|------------------------|------------------------------|-----------------------------|-----------------------|-----------------------------|--------------------------|----------------------|---------------------|-----------|-----|
| | Certified Range: | 200 to 9000 - L | В | | Max Error (%): -0.39 | 9% | Γolerance (+/-): | 0.50% | Ch | eck Cal / Shunt: | N/A | |
| | Capacity: | 9,000.00 | | | units: LB | | Indicator: | DIGITAL | | | | |
| Reading (%FS) | Nominal-UUT Indication (LB) | Resolution (LB) | Run-1 As Found (LB) | Run-1 As Found Error (LB) | Run-1 As Found Error (%) | Run-2 As Left (LB) | Run-2 As Left Error (LB) | Max Error As Left (%) | Repeatability (%) | Uncertainty (LB) | Pass/Fail | Eqp |
| 0.0% | return to zero | 0.010 | -0.490 | 0.490 | 0.01% | 0.220 | 0.000 | 0.01% | | 2.9E-03 | PASS | Α |
| 2.2% | 200.000 | 0.010 | 200.782 | -0.782 | -0.39% | 200.557 | -0.557 | -0.39% | 0.11% | 8.1E-01 | PASS | Α |
| 4.4% | 400.000 | 0.010 | 401.440 | -1.440 | -0.36% | 401.336 | -1.336 | -0.36% | 0.03% | 1.3E+00 | PASS | Α |
| 6.7% | 600.000 | 0.010 | 601.422 | -1.422 | -0.24% | 601.621 | -1.621 | -0.27% | -0.03% | 1.9E+00 | PASS | Α |
| 8.9% | 800.000 | 0.010 | 802.220 | -2.220 | -0.28% | 802.109 | -2.109 | -0.28% | 0.01% | 2.4E+00 | PASS | Α |
| 11.1% | 1,000.000 | 0.010 | 998.250 | 1.750 | 0.18% | 998.620 | 1.380 | 0.18% | -0.04% | 3.3E+00 | PASS | Α |
| 22.2% | 2,000.000 | 0.010 | 2,000.662 | -0.662 | -0.03% | 2,000.223 | -0.223 | -0.03% | 0.02% | 6.2E+00 | PASS | Α |
| 44.4% | 4,000.000 | 0.010 | 4,002.733 | -2.733 | -0.07% | 4,001.928 | -1.928 | -0.07% | 0.02% | 1.2E+01 | PASS | Α |
| 66.7% | 6,000.000 | 0.010 | 6,003.443 | -3.443 | -0.06% | 6,003.028 | -3.028 | -0.06% | 0.01% | 1.8E+01 | PASS | Α |
| 100.0% | 9,000.000 | 0.010 | 8,997.170 | 2.830 | 0.03% | 8,999.271 | 0.729 | 0.03% | -0.02% | 2.8E+01 | PASS | Α |
| | | | | | | | | | | | | |

Reported uncertainty values have been estimated at the 95% confidence level with a coverage factor of K=2 and are a combination of the reference standard uncertainty, the UUT resolution, and the UUT repeatability.

Uncertainties are reported but not combined with the UUT error for the determination of the "PASS/FAIL" status.



| | any that appry. | All applicable clauses of Astivi E4 have been | met diffess other wise floted bei | J** | | | astilicitis vveic ividae | |
|-------------|--------------------------|--|-----------------------------------|--------------------------|--------------------------|-------------|-----------------------------|--------------------------------------|
| | 3.1.12 (The Resolutio | n is stated as 1/2 the fluctuation of the indicator) | 10.1 (Readings taken be | elow 200 times the re | solution) | □ 10 | 0.5 (Does not return to ze | ero within 30-seconds) |
| Calibantian | Chandrada Haada Allas | 7.3 (Interchangeability established) | , | outside of testing mad | chine) | | 17.1 (Error or repeatabilit | ty greater than 1.0%) |
| Calibration | i Standaras Osea: All Vi | erification devices used are traceable to the Nation | ai institute oi standards and Te | chhology (MIST) | | | | |
| Eqpt Used | ID#: | Description: | Manufacturer: | Cal Date: | Cal Due: | Class-A Ten | (lb) Class-A Comp(lb) | Calibrated By: |
| | | | | | | | | |
| A | M-136B | 10-kip Class-A Load Cell | MOREHOUSE | 09/17/2019 | 09/17/2021 | 200 | 200 | Morehouse |
| A B | M-136B T-043 | 10-kip Class-A Load Cell Temperature-Humidity Meter | EXTECH | 09/17/2019 01/11/2021 | 09/17/2021 01/11/2022 | 200 | 200 | Morehouse GREAT LAKES CALIBRATION |
| A B | | | | | | 200 | 200 | |

Depath speed by Magnel Thorse Despity Tech. Mag.
Discassing Energy Englisher Section (Section Sept.)
Discassing Energy Englisher Section (Section Section Section Section Section Section Section Section Section Section Sec

QA Approval - Marya Black (QM)
Print Date: 2/16/2021 11:28

8/29/2018

LC-02

Force-1





Calibration Certificate

21081-9

Certificate #:

1490 W. Bernard Dr. Suite E

P: (630)613-9350

Addison, IL 60101 www.GreatLakesCalibration.com

Your Guide To Quality Control

This calibration was performed on-site at the address below for:

FSTL 4545 W AUGUSTA BLVD CHICAGO, IL 60804 Date of Calibration: Monday, February 8, 2021

Calibration Interval: 12 - Months
Calibration Due Date: 2/8/2022
Purchase Order: Y72041
Condition Received: Within Tolerance
Condition Returned: Within Tolerance

Equipment Information

Manufacturer: RICE LAKE N/A N/A External Cell Mfg: Display Mfg: Model Number: RL20001-T10-15K External Cell Model: N/A Display Model #: N/A Serial Number: 21583784 External Cell Serial: N/A Display Serial #: N/A Asset ID: LC-004 External Cell Asset ID: N/A Software Version: DAQ SYS1 V1.1.0.0 MECH-001 **Calibration Direction: TENSION** 73.4°F / 27%RH Work instruction: Temp / Hum: Revision: 6 Calibration Device: ASTM E-74 LOAD CELL Technician: Abelardo Garcia Specification: ASTM E4-2020 Calibration Method: FOLLOW THE FORCE Page: 1 of 1 Description: 9,000-lb Load Cell

The data contained within this report pertains only to the item(s) as described above. This report shall not be reproduced except in full without the prior written approval of Great Lakes Calibration, Inc.

The calibration was performed in accordance with the most current revision of work instruction MECH-001 (which is based off the requirements of ASTM E-4) and the governing specification listed above and is compliant with ISO/IEC 17025:2017,


ANS/NCSL Z540-1-1994, ISO9000, and TS-16949.

The calibration device(s) used is either a Class-A temperature Compensated load cell that has been certified by an accredited laboratory in accordance with ASTM E-74 or certified Dead weights.

| | | | | | Calibration Da | ta (TENSION) | | | | | | |
|------------------|--------------------------------|--------------------|------------------------|------------------------------|-----------------------------|-----------------------|-----------------------------|--------------------------|----------------------|---------------------|-----------|-----|
| | Certified Range: | 1000 to 9000 - | LB | | Max Error (%): 0.16% | | Tolerance (+/-): | 0.50% | Ch | eck Cal / Shunt: | N/A | |
| | Capacity: | 9,000.00 | | | units: LB | | Indicator: | DIGITAL | | | | |
| Reading (%FS) | Nominal-UUT Indication (LB) | Resolution (LB) | Run-1 As Found (LB) | Run-1 As Found Error (LB) | Run-1 As Found Error (%) | Run-2 As Left (LB) | Run-2 As Left Error (LB) | Max Error As Left (%) | Repeatability (%) | Uncertainty (LB) | Pass/Fail | Eqp |
| 0.0% | return to zero | 0.100 | 0.090 | -0.090 | 0.00% | 0.112 | 0.000 | 0.00% | | 2.9E-02 | PASS | А |
| 11.1% | 1,000.000 | 0.100 | 1,001.434 | -1.434 | -0.14% | 1,001.202 | -1.202 | -0.14% | 0.02% | 3.2E+00 | PASS | Α |
| 25.0% | 2,250.000 | 0.100 | 2,248.830 | 1.170 | 0.05% | 2,250.829 | -0.829 | 0.05% | -0.09% | 8.6E+00 | PASS | 4 |
| 50.0% | 4,500.000 | 0.100 | 4,493.182 | 6.818 | 0.15% | 4,495.553 | 4.447 | 0.15% | -0.05% | 1.5E+01 | PASS | Α |
| 75.0% | 6,750.000 | 0.100 | 6,739.270 | 10.730 | 0.16% | 6,741.283 | 8.717 | 0.16% | -0.03% | 2.2E+01 | PASS | Α |
| 100.0% | 9,000.000 | 0.100 | 8,986.240 | 13.760 | 0.15% | 8,988.109 | 11.891 | 0.15% | -0.02% | 2.8E+01 | PASS | Α |
| | | | | | | | | | | | | - 1 |

Reported uncertainty values have been estimated at the 95% confidence level with a coverage factor of K=2 and are a combination of the reference standard uncertainty, the UUT resolution, and the UUT repeatability.

Uncertainties are reported but not combined with the UUT error for the determination of the "PASS/FAIL" status.



| спеск а | iny that apply: | All applicable clauses of ASTIVI E4 have been | .net uniess otherwise noted t | Delow | | Aujust | nents were iviace | | | | | | |
|-------------|--|---|-------------------------------|---------------------------|------------|------------------|------------------------|-------------------------|--|--|--|--|--|
| | 3.1.12 (The Resolu | tion is stated as 1/2 the fluctuation of the indicator) | 10.1 (Readings taken | below 200 times the res | solution) | 10.5 | Does not return to ze | ro within 30-seconds) | | | | | |
| | | 7.3 (Interchangeability established) | Annex A1 (Verifie | ed outside of testing mac | hine) | 17.1 | (Error or repeatabilit | y greater than 1.0%) | | | | | |
| Calibration | libration Standards Used: All verification devices used are traceable to the National Institute of Standards and Technology (NIST) | | | | | | | | | | | | |
| Eqpt Used | ID#: | Description: | Manufacturer: | Cal Date: | Cal Due: | Class-A Ten (lb) | Class-A Comp(lb) | Calibrated By: | | | | | |
| Α | M-136B | 10-kip Class-A Load Cell | MOREHOUSE | 09/17/2019 | 09/17/2021 | 200 | 200 | Morehouse | | | | | |
| В | T-043 | Temperature-Humidity Meter | EXTECH | 01/11/2021 | 01/11/2022 | | | GREAT LAKES CALIBRATION | | | | | |
| | | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| | | | | | | | | | | | | | |

Customer Approval

8/29/2018

QA Approval - Marya Black (QM)
Print Date: 2/16/2021 11:30

Force-1





Calibration Certificate

21081-15

1490 W. Bernard Dr. Suite E

P: (630)613-9350

Addison, IL 60101 www.GreatLakesCalibration.com

Your Guide To Quality Control

This calibration was performed on-site at the address below for:

FSTL 4545 W AUGUSTA BLVD CHICAGO, IL 60804 Date of Calibration: Monday, February 8, 2021

Certificate #:

Calibration Interval: 12 - Months
Calibration Due Date: 2/8/2022
Purchase Order: Y72041
Condition Received: Within Tolerance
Condition Returned: Within Tolerance

Equipment Information

Manufacturer: N/A N/A **OMEGA** External Cell Mfg: Display Mfg: Model Number: LCCA-15K External Cell Model: N/A Display Model #: N/A Serial Number: 611769 External Cell Serial: N/A Display Serial #: N/A Asset ID: LC-006 External Cell Asset ID: N/A Software Version: DAQ SYS1 V1.1.0.0 MECH-001 **Calibration Direction: TENSION** 73.8°F / 27%RH Work instruction: Temp / Hum: Revision: 6 Calibration Device: ASTM E-74 LOAD CELL Technician: Abelardo Garcia Specification: ASTM E4-2020 Calibration Method: FOLLOW THE FORCE Page: 1 of 1 Description: 9,000-lb Load Cell

The data contained within this report pertains only to the item(s) as described above. This report shall not be reproduced except in full without the prior written approval of Great Lakes Calibration, Inc.

The calibration was performed in accordance with the most current revision of work instruction MECH-001 (which is based off the requirements of ASTM E-4) and the governing specification listed above and is compliant with ISO/IEC 17025:2017,


ANS/NCSL Z540-1-1994, ISO9000, and TS-16949.

The calibration device(s) used is either a Class-A temperature Compensated load cell that has been certified by an accredited laboratory in accordance with ASTM E-74 or certified Dead weights.

| | | | | | Calibration D | ata (TENSION) | | | | | | |
|------------------|--------------------------------|--------------------|------------------------|------------------------------|-----------------------------|-----------------------|-----------------------------|--------------------------|----------------------|---------------------|-----------|------------|
| | Certified Range: | 1000 to 9000 - | LB | | Max Error (%): 0.11% | | Tolerance (+/-): | 0.50% | Ch | eck Cal / Shunt: | N/A | |
| | Capacity: | 9,000.00 | | | units: LB | | Indicator: | DIGITAL | | | | |
| Reading (%FS) | Nominal-UUT Indication (LB) | Resolution (LB) | Run-1 As Found (LB) | Run-1 As Found Error (LB) | Run-1 As Found Error (%) | Run-2 As Left (LB) | Run-2 As Left Error (LB) | Max Error As Left (%) | Repeatability (%) | Uncertainty (LB) | Pass/Fail | Eqp Use |
| 0.0% | return to zero | 0.100 | 0.660 | -0.660 | -0.01% | 0.334 | 0.000 | -0.01% | | 2.9E-02 | PASS | Α |
| 11.1% | 1,000.000 | 0.100 | 999.655 | 0.345 | 0.03% | 999.552 | 0.448 | 0.04% | 0.01% | 3.0E+00 | PASS | Α |
| 25.0% | 2,250.000 | 0.100 | 2,248.523 | 1.477 | 0.07% | 2,248.412 | 1.588 | 0.07% | 0.00% | 6.7E+00 | PASS | 4 |
| 50.0% | 4,500.000 | 0.100 | 4,502.630 | -2.630 | -0.06% | 4,501.280 | -1.280 | -0.06% | 0.03% | 1.4E+01 | PASS | Α |
| 75.0% | 6,750.000 | 0.100 | 6,744.280 | 5.720 | 0.08% | 6,747.726 | 2.274 | 0.08% | -0.05% | 2.3E+01 | PASS | Α |
| 100.0% | 9,000.000 | 0.100 | 8,990.230 | 9.770 | 0.11% | 8,992.877 | 7.123 | 0.11% | -0.03% | 2.9E+01 | PASS | Α |
| | | | | | | | | | | | | 1 |

Reported uncertainty values have been estimated at the 95% confidence level with a coverage factor of K=2 and are a combination of the reference standard uncertainty, the UUT resolution, and the UUT repeatability.

Uncertainties are reported but not combined with the UUT error for the determination of the "PASS/FAII" status.



| CHECK | iny that appry. | All applicable clauses of ASTW 24 have been t | net amess other wise noted bere | ,,,, | | | ments were made | |
|-------------|------------------------|---|-----------------------------------|-----------------------|------------|------------------|------------------------|-------------------------|
| | 3.1.12 (The Resolution | on is stated as 1/2 the fluctuation of the indicator) | 10.1 (Readings taken be | elow 200 times the re | solution) | 10.5 | Does not return to ze | ero within 30-seconds) |
| | | 7.3 (Interchangeability established) | Annex A1 (Verified o | · · | thine) | 17.1 | (Error or repeatabilit | ty greater than 1.0%) |
| Calibration | Standards Used: All | verification devices used are traceable to the Nation | al Institute of Standards and Tec | chnology (NIST) | | | | |
| Eqpt Used | ID#: | Description: | Manufacturer: | Cal Date: | Cal Due: | Class-A Ten (lb) | Class-A Comp(lb) | Calibrated By: |
| Α | M-136B | 10-kip Class-A Load Cell | MOREHOUSE | 09/17/2019 | 09/17/2021 | 200 | 200 | Morehouse |
| В | T-043 | Temperature-Humidity Meter | EXTECH | 01/11/2021 | 01/11/2022 | | | GREAT LAKES CALIBRATION |
| | | | | | | | | |
| | | | | | | | | |

All applicable clauses of ASTM E4 have been met upless otherwise noted below

Customer Approval

8/29/2018

QA Approval - Marya Black (QM)
Print Date: 2/16/2021 14:10

Adjustments Were Made

Force-1

Work Order No.: 2107B4 Page 30 of 30





Calibration Certificate

21081-2

Certificate #:

1490 W. Bernard Dr. Suite E

P: (630)613-9350

Addison, IL 60101 www.GreatLakesCalibration.com

Your Guide To Quality Control

This calibration was performed on-site at the address below for:

FSTL 4545 W AUGUSTA BLVD CHICAGO, IL 60804 Date of Calibration: Monday, February 8, 2021

Calibration Interval: 12 - Months

Calibration Due Date: 2/8/2022
Purchase Order: Y72041

Condition Received: Within Tolerance

Condition Returned: Within Tolerance

Equipment Information

Manufacturer: INTERFACE N/A N/A External Cell Mfg: Display Mfg: Model Number: SSM2-AF-10K External Cell Model: N/A Display Model #: N/A Serial Number: 1015713 External Cell Serial: N/A Display Serial #: N/A Asset ID: LC-015 External Cell Asset ID: N/A Software Version: DAQ SYS1 V1.1.0.0 MECH-001 **Calibration Direction: TENSION** 73.5°F / 26%RH Work instruction: Temp / Hum: Revision: 6 Calibration Device: ASTM E-74 LOAD CELL Technician: Abelardo Garcia Specification: ASTM E4-2020 Calibration Method: FOLLOW THE FORCE Page: 1 of 1 Description: 9,000-lb Load Cell

The data contained within this report pertains only to the item(s) as described above. This report shall not be reproduced except in full without the prior written approval of Great Lakes Calibration, Inc.

The calibration was performed in accordance with the most current revision of work instruction MECH-001 (which is based off the requirements of ASTM E-4) and the governing specification listed above and is compliant with ISO/IEC 17025:2017,


ANS/NCSL Z540-1-1994, ISO9000, and TS-16949.

The calibration device(s) used is either a Class-A temperature Compensated load cell that has been certified by an accredited laboratory in accordance with ASTM E-74 or certified Dead weights.

| | | | | | Calibration D | ala (TENSION) | | | | | | |
|------------------|--------------------------------|--------------------|------------------------|------------------------------|-----------------------------|-----------------------|-----------------------------|--------------------------|-------------------|---------------------|-----------|-----|
| | Certified Range: | 1000 to 9000 - | LB | | Max Error (%): -0.26% | | Tolerance (+/-): | 0.50% | Ch | eck Cal / Shunt: | N/A | |
| | Capacity: | 9,000.00 | | | units: LB | | Indicator: | DIGITAL | | | | |
| Reading (%FS) | Nominal-UUT Indication (LB) | Resolution (LB) | Run-1 As Found (LB) | Run-1 As Found Error (LB) | Run-1 As Found Error (%) | Run-2 As Left (LB) | Run-2 As Left Error (LB) | Max Error As Left (%) | Repeatability (%) | Uncertainty (LB) | Pass/Fail | Eqp |
| 0.0% | return to zero | 0.010 | 0.610 | -0.610 | -0.01% | 0.440 | 0.000 | -0.01% | | 2.9E-03 | PASS | Α |
| 11.1% | 1,000.000 | 0.010 | 997.820 | 2.180 | 0.22% | 998.109 | 1.891 | 0.22% | -0.03% | 3.2E+00 | PASS | A |
| 25.0% | 2,250.000 | 0.010 | 2,255.830 | -5.830 | -0.26% | 2,254.450 | -4.450 | -0.26% | 0.06% | 7.9E+00 | PASS | 4 |
| 50.0% | 4,500.000 | 0.010 | 4,511.720 | -11.720 | -0.26% | 4,511.152 | -11.152 | -0.26% | 0.01% | 1.4E+01 | PASS | Д |
| 75.0% | 6,750.000 | 0.010 | 6,762.830 | -12.830 | -0.19% | 6,764.433 | -14.433 | -0.21% | -0.02% | 2.1E+01 | PASS | Α |
| 100.0% | 9,000.000 | 0.010 | 9,009.620 | -9.620 | -0.11% | 9,010.727 | -10.727 | -0.12% | -0.01% | 2.7E+01 | PASS | Α |
| | | | | | | | | | | | | |

Reported uncertainty values have been estimated at the 95% confidence level with a coverage factor of K=2 and are a combination of the reference standard uncertainty, the UUT resolution, and the UUT repeatability.

Uncertainties are reported but not combined with the UUT error for the determination of the "PASS/FAII" status.



| спеск а | iny that apply: | All applicable clauses of ASTIVI E4 have been | .net uniess otherwise noted t | Delow | | Aujust | nents were iviace | | | | | | |
|-------------|--|---|-------------------------------|---------------------------|------------|------------------|------------------------|-------------------------|--|--|--|--|--|
| | 3.1.12 (The Resolu | tion is stated as 1/2 the fluctuation of the indicator) | 10.1 (Readings taken | below 200 times the res | solution) | 10.5 | Does not return to ze | ro within 30-seconds) | | | | | |
| | | 7.3 (Interchangeability established) | Annex A1 (Verifie | ed outside of testing mac | hine) | 17.1 | (Error or repeatabilit | y greater than 1.0%) | | | | | |
| Calibration | libration Standards Used: All verification devices used are traceable to the National Institute of Standards and Technology (NIST) | | | | | | | | | | | | |
| Eqpt Used | ID#: | Description: | Manufacturer: | Cal Date: | Cal Due: | Class-A Ten (lb) | Class-A Comp(lb) | Calibrated By: | | | | | |
| Α | M-136B | 10-kip Class-A Load Cell | MOREHOUSE | 09/17/2019 | 09/17/2021 | 200 | 200 | Morehouse | | | | | |
| В | T-043 | Temperature-Humidity Meter | EXTECH | 01/11/2021 | 01/11/2022 | | | GREAT LAKES CALIBRATION | | | | | |
| | | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| | | | | | | | | | | | | | |

Customer Approval

8/29/2018

QA Approval - Marya Black (QM)
Print Date: 2/16/2021 9:41

LC-015

Force-1